



General installation and maintenance directives concerning factory guarantee. Connecting and testing the lamps must always happen by an acknowledged electrician according to the locally applying regulations on electric installations. Do not place on a flammable surface. All class I lamps must be earthed in the cable clamp marked with a \oplus -sign. Class II lamps may not be earthed. Disconnect from the main supply when fitting lamp or changing bulb.

This lamp satisfies to the low tension directive 73/23/EEG with modification 93/68/EEG and the EMC directive 89/336/EEG with modifications 92/31/EEG and 93/68/EEG.

Algemene installatie en onderhoudsrichtlijnen m.b.t. fabrieksgarantie. Het aansluiten en uittesten van de toestellen dient altijd te gebeuren door een erkend elektricien volgens de nationaal geldende reglementen op elektrische installaties. Niet op een brandbaar oppervlak bevestigen. Niet reinigen met solventen en detergenten. Alle klasse I-toestellen dienen te worden geaard in de met een \oplus -teken gemarkeerde kabelklem. Klasse II-toestellen mogen niet worden geaard. De elektriciteitstoever dient te worden onderbroken bij het plaatsen van het toestel en het vervangen van de lamp.
Het toestel voldoet aan de laagspanningsrichtlijn 73/23/EEG met wijziging 93/68/EEG en de EMC-richtlijn 89/336/EEG met wijzigingen 92/31/EEG en 93/68/EEG.

Karvelstraat 2
8380 Zeebrugge, Belgium

T +32 (0)50 54 35 49

F +32 (0)50 54 35 40

E info@tossb.com

W www.tossb.com

tossB reserves the right to alter materials, dimensions and characteristics without prior notice. This documentation replaces all previous documentation. Read the installation-instructions carefully.

Our general terms and conditions shall apply notwithstanding any stipulation to the contrary to all the orders and agreements with tossB. You can obtain a copy of these conditions on demand.

Product documentation © tossB 2009. All rights reserved.